

PARTS LIST

Part	Description	Qty	Part	Description	Qty
1	Rag wheel	1	25	608 bearing leather collar	1
2	Output spindle	1	26	Screw	2
3	Semicircle key $\varnothing 10 \times 3$	1	27	Guided ring	1
4	Pan head screws $m5 \times 14$	4	28	Stator	1
5	Front cover	1	29	Housing	1
6	Bearing 6201-2rs	1	30	Coil spring	2
7	Pan head screws $m4 \times 8$	3	31	Carbon brush	2
8	D type handle	1	32	Brush holder	1
9	Gear	1	33	Screw	2
10	Retainer ring $\varnothing 12$	1	34	Right cover	1
11	Needle roller bearings hk0810	1	35	Screw	2
12	Hexagon socket head cap screws	2	36	Speed controller cover	1
13	Handle set piece	2	37	Switch(right self-lock)	1
14	Screw	4	38	right handle	1
15	Gear box	1	39	Screw	6
16	Retainer ring $\varnothing 12$	1	41	Cable cover	1
17	Lock pin spring	1	42	Cable plug	1
18	Lock pin	1	43	Cable pressboard	1
19	Retainer ring $\varnothing 12$	1	44	Screw	2
20	Bearing 6001	1	45	Speed controller	1
21	Screw	3	46	Left handle	1
22	Rotor	1	47	Left cover	1
23	Spanner	1	48	Brush holder	1
24	Bearing 608	1			

ASSEMBLY DIAGRAM

