



ASSEMBLY DIAGRAM



PARTS LIST

NO.	DESCRIPTION	QTY	NO.	DESCRIPTION	QTY
1	Motor assembly	1	23	Screw	4
2	Guide board	1	24	Control assembly	1
3	screw	4	25	Flat washer	4
4	Rack rod	1	26	Spring Washer	4
5	Right guide board	1	27	Screw	4
6	screw	3	28	Cable	1
7	Corrugated pipe	1	29	Screw	1
8	screw	4	30	Cord Clamp	1
9	Label	1	31	Cable mount	1
10	screw	8	32	Screw	1
11	Left guide board	1	33	Screw	1
12	screw	5	34	Nut	1
13	Regulation Sleeve	1	35	Grounding column	1
14	Shaft sleeve	1	36	Cable sheath	1
15	Bellows joint	1	37	Screw	2
16	rack	1	38	Connecting rod	1
17	Oil can assembly	1	39	Hex Wrench	1
18	Handle lever	3	40	Pin	1
19	Handle shaft	1	41	Safety belt	1
20	Shaft sleeve	1	42	Hex Wrench	1
21	Electromagnet	1	43	Morse sleeve	1
22	External water injection device	1			

ASSEMBLY DIAGRAM (MOTOR ASSEMBLY)



PARTS LIST (MOTOR ASSEMBLY)

NO.	DESCRIPTION	QTY	NO.	DESCRIPTION	QTY
1	Circlip	1	23	Screw	2
2	Anti oil ring	1	24	Stator	1
3	Spindle	1	25	Lead wire	1
4	Square pin	1	26	Lead wire	1
5	Bearing	1	27	Housing	1
6	Screw	4	28	Screw	2
7	Speed reduction box	1	29	Carbon brush	2
8	Cylindrical pin	1	30	Brush holder	2
9	Bearing	1	31	Screw	4
10	Big gear	1	32	Coil spring	2
11	Circlip	1	33	Speed control module	1
12	Bearing	3	34	Screw	2
13	Minor shaft	1	35	Screw	4
14	Square pin	1	36	Cap of carbon brush	1
15	Middle gear	1	37	Connect nut	1
16	Bearing holder	1	38	Rear cover	1
17	Bearing	1	39	Screw	4
18	Circlip	1	40	Bellows joint	1
19	Rotor	1	41	Lead wire	1
20	Anti wind ring	1	42	Lead wire	1
21	Bearing sleeve	1			
22	Sensors	1			