

PARTS LIST

Part	Description	Qty	Part	Description	Qty
1	Outer Flange	1	31	Creeper retaining ring	1
2	Grinding wheel	1	32	Gasket 8 *18.5 *0.3	1
3	Inner Flange	1	33	608 bearings	1
4	Grinding wheel cover	1	34	608 bearing sleeve	1
5	Dust cover	1	35	Screw ST4 *75 (Type C)	2
6	Output shaft	1	36	Windshield ring	1
7	Screw M5 *16	4	37	Stator	1
8	Front cover	1	38	Lebal	1
9	O-ring Φ 58 *2	1	39	Motor housing	1
10	6202 bearing	1	40	Screw ST4 *12 (C-type)	2
11	6202 bearing cover	1	41	Screw ST4 *12 (F-type)	2
12	Screw M4 *12	3	42	Carbon brush cover	2
13	Big gear	1	43	Carbon brush	2
14	608 bearing (iron cover)	1	44	brush holder	2
15	self-lock pin	1	45	Coil spring	2
16	O-ring Φ 6 *1.8	1	46	Button spring	1
17	Slinger	1	47	Rotate button	1
18	Pinion	1	48	Left handle	1
19	Nut M8 *1	1	49	Switch	1
20	Screw ST4.8 *30	4	50	Cable sheath	1
21	Self-locking cap	1	51	Cable	1
22	Self-locking spring	1	52	Cable pressure plate	1
23	Head	1	53	Screw ST4 $\times$ 14 (C-type)	2
24	O-ring Φ 31.5 *2	1	54	Lead wire crimping board	1
25	6201 bearing	1	55	Screw ST3 $\times$ 10 (C-type)	2
26	Shim	1	56	Right handle	1
27	Wind guide ring	1	57	Screw ST4 $\times$ 16 (F-type)	5
28	Screw M5 *12	2	58	Auxiliary handle	1
29	Cylinder pin gasket	1	59	Wrench	1
30	Rotor	1	60	Hexagonal wrench	1

ASSEMBLY DIAGRAM

