

PARTS LIST

Part	Description	Qty
1	ScrewM5*18	1
2	Chuck10mm	1
3	ScrewST3×14	18
4	Gear Box	1
5	Right Housing	1
6	Lamp shade	1
7	Reverse button	1
8	Gear	1
9	Controller components + switche + stator	1
10	Speed change button	1
11	Steel wire	1
12	Rotor	1
13	Rear cover	1
14	Right Buttom Housing	1
15	Plastic Cover	1
16	Makita Plug Type	1
17	Left Housing	1
18	Left Buttom Housing	1
19	Battery	1
20	Charger	1

ASSEMBLY DIAGRAM

