

WOKIN CORDLESS DRILL 20V | 622010

PARTS LIST

Part	Description	Qty	Part	Description	Qty
1	Screw M5*18	1	13	Screw M3*6	2
2	Chuck 10mm	1	14	Gear box cover	1
3	Right Housing	1	15	Motor	1
4	Screw ST3*14	11	16	Left Housing	11
5	Torsion cup	1	17	Right Buttom Housing	1
6	Gear Box	1	18	Plastic Cover	1
7	Torque shrapnel	1	19	Makita Plug Type	1
8	Steelwire	1	20	Left Buttom Housing	1
9	Speed change button	1	21	Left Buttom Housing	1
10	Switch+LED light	1	22	Screw ST4*10	1
11	Reversing push button	1	23	Battery	1
12	Motor gear	1	24	Charger	1

ASSEMBLY DIAGRAM

