

PARTS LIST

No.	Description	Qty	No.	Description	Qty
1	Hex.Soc.Hd.Bolt	6	33	Stepped Pin	1
2	Spring Washer	10	34	Spring	1
3	Side protector	2	35	Safety Trigger	1
4	Protective pad	2	36	O-Ring	2
5	Exhaust Cover	1	37	Stepped Pin	1
6	Deflector	1	38	Trigger	1
7	Seal	1	39	Joint Guide	1
8	Spring	1	40	Spacer	1
9	O-Ring	1	41	Hex.Soc.Hd.Bolt	2
10	Hd.Valve Piston	1	42	Driver Guide Cover	1
11	O-Ring	2	43	Spring Pin	2
12	Seal	1	44	Fixed clip	1
13	O-Ring	1	45	Hex.Soc.Hd.Bolt	1
14	Driver Unit	1	46	Stop Plate	1
15	Shrink ring	1	47	Tail Hanger	1
16	O-Ring	1	48	Hex.Soc.Hd.Bolt	1
17	Cylinder	1	49	Gun head	1
18	O-Ring	1	50	Pin	2
19	Bumper	1	51	Movable slip	1
20	Packing	1	52	Pusher	1
21	Gun Body	1	53	Spring Pin	1
22	Rubber part	1	54	Pulley	1
23	O-Ring	1	55	Spring	1
24	End Cap	1	56	Spring Pin	2
25	Pipe joints	1	57	Position seat	1
26	Seal	1	58	Hex.Soc.Hd.Bolt	1
27	Trigger Valve Hd	1	59	Stepped Pin	1
28	O-Ring	1	60	O-Ring	1
29	Valve Stem	1	61	Spring	1
30	O-Ring	1	62	Fixed hook	1
31	Trigger Valve Guide	1	63	Hex.Soc.Hd.Bolt	1
32	Spring	1			

ASSEMBLY DIAGRAM

