

PARTS LIST(ENGINE PARTS)

Part	Description	Qty	Part	Description	Qty
1	recoil satrtter assembly	1	41	gasket (carburetor)	1
2	bolt	3	42	insulation board (carburetor)	1
3	bolt	18	43	gasket(intake	1
4	fan case	1	44	bolt	2
5	nut M14X1.5	1	45	cylinder head	1
6	Starting pulley	1	46	qsaket (cylinder head)	1
7	flywheel	1	47	intake vavle	1
8	rotor	1	48	exhaust vavle	1
9	stator	1	49	vavle lifter	1
10	oil seal	2	50	camshaft assembly	1
11	bearing	2	51	waste pipe	1
12	crank case	1	52	exhaust vavle spring retainer	1
13	oil alert	1	53	intake vavle spring retainer	1
14	bolt	2	54	vavle spring	1
15	lower cover	1	55	Oil baffle cover	1
16	wind scooper cylinder	1	56	Valve adjusting cap	1
17	bolt M10X1.25X15	2	57	spark plug	1
18	gasket 10X 15.8X1.5	2	58	bolt	4
19	crankshaft	1	59	nut	2
20	qsaket (crankshaft)	1	60	nut	2
21	oil quage set	1	61	vavle rocker arm	2
22	crankcase cover set	1	62	bolt	2
23	flip-flop	1	63	plate push guide	1
24	bolt	6	64	gasket(cylinder head)	1
25	muffler holder	1	65	Clinder Head Cover	1
26	location pin 8×14	2	66	wind scooper	1
27	connecting rod	1	67	air cleaner	1
28	piston	1	68	vavle lifter	2
29	piston pin	1	69	gasket(exhaust vavle)	1
30	clip(piston pin)	2	70	double-screw M8X34	2
31	piston ring	1	71	fuel pipe	1
32	piston ring	1	72	clamp (fuel pipe)	1
33	piston ring	1	73	nut M8	2
34	muffler	1	74	wire clamp	3
35	ignitor coil	1	75	bolt M6X55	3
36	bolt M6*25	2	76	stepping motor	1
37	bolt M8*60	4	77	oil protector	1
38	location pin	2	78	starting relay	1
39	gsaket(air cleaner)	1	79	Start motor parts	1
40	carburetor	1	80	bolt	2


791363

3700W
MAX OUTPUT POWER

SILENT INVERTER GENERATOR

WOKIN

ASSEMBLY DIAGRAM(ENGINE PARTS)



PARTS LIST(UNIT PARTS)

Part	Description	Qty	Part	Description	Qty
1	170Fpi Engine	1	42	Cover Plate	1
2	Muffler Heat Shield	1	43	Screw	6
3	Fly Wheel	1	44	Starting Handle	1
4	Impeller Casing	1	45	Battery Plate	1
5	Bolt M8*25	4	46	Accumulator	1
6	Muffler	1	47	Pulling Plate	1
7	Muffler Fixed Supportor	1	48	Left Rear Pillar Assembly	1
8	Gasket(Exhaust Vavle)	1	49	Left Front Column	1
9	Muffler Air Hood	1	50	Nut	16
10	Soundproof Cotton	1	51	Cover Plate Clip	9
11	Muffler Tail Cover	1	52	Bolt	4
12	Hand Push Rod Assembly	1	53	Left Frame	1
13	Fuel Tank Mounting Plate	2	54	Cover Plate	1
14	Fuel Tank	1	55	Shochproof Foot	4
15	Fuel Filter	1	56	Baseplate	1
16	Fuel Tank Cap	1	57	Nut	4
17	Bolt M6x55	4	58	Base Support Assembly	1
18	Flat Washer 6× 22×2	4	59	Shock Absorber(Base Support)	2
19	Rubber Gasket(Damping)	4	60	Bolt M6×20	2
20	Bushing	4	61	Inverter	1
21	Clamp (Fuel Pipe)	3	62	Alertor	1
22	Tie Rod Fixation Plate(Behind)	1	63	Inverter Mounting Plate	1
23	Oil Spill Mouth Rubber Sleeve	1	64	Nut	20
24	Oil Mark Observation Window	1	65	Panel Cover	1
25	Shock Absorbing Rubber	1	66	Panel	1
26	Upper Cover	1	67	Screw	
27	Screw	2	68	3 In 1 Indicator	1
28	Pull Rod	1	69	Oil Switch Assembly	1
29	Tie Rod Fixation Plate(Front)	1	70	Parallel Socket	1
30	Screw St5.5×12	12	71	Parallel Socket	1
31	Bolt M6×12	21	72	Circuit Breaker	1
32	Fuel Pipe	1	73	Idling Switch	1
33	Right Rear Pillar Assembly	1	74	Reset Switch	1
34	Wheel Clamp 15	2	75	Power Socket Combination	1
35	Flat Washer 16× 30×2	2	76	Socket (Eu 16a)	2
36	Front Wheel	2	77	Bolt	1
37	Bolt M8×12	2	78	Control Panel Assembly	1
38	Pulling Plate	1	79	Flat Washer 8.5× 23×2	2
39	Right Front Column	1	80	Bolt	1
40	Right Frame	1	81	Flat Washer 8× 18×2	1
41	Screw St5×30	4	82	Screw M5×16	16

ASSEMBLY DIAGRAM(UNIT PARTS)

