


WOKIN RECIPROCATING SAW 710W | 854671

ASSEMBLY DIAGRAM



PARTS LIST

Part	Description	Qty	Part	Description	Qty
1	Screw ST4×16	13	23	Lock spring	2
2	Right handle	1	24	Gear box	1
3	Allen 4	1	25	Steel jacket	1
4	Cable	1	26	Spindle	1
5	Cable jacket	1	27	Steel jacket	1
6	Screw ST4×14	2	28	Big gear	1
7	Strain relief	1	29	Pin	1
8	Left handle	1	30	Needle bearing	1
10	Switch	1	31	Reciprocating lever	1
11	Carbon brush holder	2	32	Sliding block	1
12	Carbon brush	2	33	Pin	2
13	Carbon brush cover	2	34	Slide wedge	2
14	Housing	1	35	Screw M5×12	4
15	Stator	1	36	Plastic cover	1
16	Screw ST4×45	2	37	Screw M4×14	4
17	Wind-proof circle	1	38	Left gear box cover	1
18	607 bearing cover	1	39	Screw ST4×18	4
19	607Z (B) bearing	1	40	Right gear box cover	1
20	Rotor	1	41	M5×12 Screw	2
21	Screw M5×8	4	42	Blade holder system	1
22	6000RS bearing	2			