

PARTS LIST

Part	Description	Part	Description
1	Connection	19	Stator Assembly
2	Washer	20	Seal Gasket
3	Pump body	21	Screw
4	Washer	22	Pump Barrel
5	Water Flow Switch	23	Name Plate
6	Screw	24	O ring
7	Seal gasket	25	Bleeder Screw
8	O Ring	26	Washer
9	Impeller	27	Cable Protector
10	Baffle Cover	28	Electrical Box Bottom Cover
11	Ceramic Ring	29	Fastening Screw
12	Seal Gasket	30	Circuit Board
13	Graphite Ring	31	Fastening Screw
14	Washer	32	Cable Fixed Clip
15	Rotor Assembly	33	Capacitor
16	Location Gasket	34	Electrical Box Upper Cover
17	Ceramic Bearing	35	Fixed Screw
18	Shield Sleeve	36	Knob

ASSEMBLY DIAGRAM

