


PARTS LIST

Part	Description	Qty
1	Hex nut of hand wheel 0.8T:M6*12mm/1.6-9T:M8*12mm	1
2	Hand wheel	1
3	Screw bolt 0.8T:M6*12mm/1.6-9T:M8*12mm	2
4	Washer of screw bolt	2
5	Lever handle assembly	1
5-1	Lever handle	1
5-2	Selector	1
5-3	Washer of lever handle	1
5-4	Pin of selector	1
5-5	Bolt	2
5-6	Spring seat	1
6	Change over pawl	1
7	Shaft of change over pawl	1
8	Shaft of change over pawl	1
9	Locking plate	1
10	Change over gear	1
11	Hex nut of cover 0.8T:M8/1.6T:M10/3.2-9T:M12	8
12	Brake cover	1
13	Inner cover assembly	1
13-1	Inner cover	2
13-2	Bolt	1
5-3	Washer of lever handle	1
14	Hex nut of inner cover 0.8T:M6/1.6-9T:M8	1
15	Spring of pinion shaft	2
16	Friction disc	1
17	Ratchet disc	1
18	Brake seat	2
19	Snap ring	2
20	Pawl	2
21	Spring of pawl	1
22	Side plate assembly A	1
22-1	Left side plate	2
22-2	Pin of pawl	1
23	Load chain cover	2
24	Needle bearing	1
25	Chain sprocket	1
26	Stripper	1
27	Side plate assembly B	1
27-1	Right side plate	1
27-2	Steel ring	2
27-3	Support pin	4
28	Disc gear assembly	2
28-1	Gear 1st	2
28-2	Gear 2nd	2
29	Pinion shaft	1
30	Splined gear	1
31	Snap ring	1
32	Gear cover Assembly	1

PARTS LIST

Part	Description	Qty
32-1	Gear cover	1
32-2	Cover	1
32-3	Rivet of gear cover: 2.5*6mm	2
27-2	Steel ring	2
33	Top hook shaft	1
34	Top Hook Assembly	1
34-1	Top Hook	1
34-2	Pin of safety latch	2
34-3	Hex nut of safety latch M4	2
34-4	Spring of safety latch	2
34-5	Safety latch	1
34-6	Rivet of top hook's housing 0.8T:5-20mm/1.6T:6*20mm/3.2T:8*25mm	2
34-7	Top hook's housing	2
34-8	Suspension pin of top hook housing	1
34-9	Top hook's housing A	1
34-10	Top hook's housing B	1
34-11	Hex nut of safety latch of bottom hook M4	1
35	Load chain	1
36	Suspension pin of bottom hook housing	1
37	Hex Nut of suspension pin 0.8T:M6/1.6T:M8/3.2-9T:M10	1
38	Bottom hook Assembly	1
38-1	Bottom Hook	1
38-2	Bottom hook's housing	2
38-3	Bearing Sleeve of bottom hook	2
38-4	Ball bearing of bottom hook	
38-5	Screw of bottom hook's housing M8*35mm	3
38-6	Needle of Axle of bottom hook	26
38-7	Shaft of Axle of bottom hook	1
38-8	Axle of bottom hook	1
38-9	Hex nut of safety latch of bottom hook M4	3
38-10	Rivet of bottom hook's housing 0.8T:520mm/1.6T:6*20mm/3.2T:Ø8*25mm	4
38-11	Split Ring	1
39	End anchor	1
40	Hand Grip	1
41	Lock nut:M3.5*6mm	1
42	Screw of hand:M3.5*6mm	1
43	Pin of end anchor	1
44	Hex nut of end anchor: 0.75&1.5,M6;3-9T,M8	1
45	Nameplate	1
46	Rivet of nameplate: 2.5X4mm	6
10-1	Locking nut of overload protection	1
10-2	Brake seat ring of overload protection.	1
10-3	Flat washer of overload protection	2
10-4	Spring of overload protection	1
10-5	Clamp of overload protection	1
10-6	Friction disc of overload protection	2
10-7	Ratchet gear of overload protection	1
10-8	Brake seat of overload protection	1

ASSEMBLY DIAGRAM



LEVER BLOCK CHAIN HOIST