

PARTS LIST

Part	Description	Qty	Part	Description	Qty
1	Scale plate	1	45	Upper guard	1
2	Active cover	1	46	Selflocking pin	1
3	Flat washer 6×14×1.5	1	47	Compression spring 7.8× 0.7×2	1
4	Knob for scale plate	1	48	Washer 5	1
5	Active cover	1	49	ScrewST4,2×25-F	4
6	Brand label	1	50	Allen screw M8	1
7	Knob for active cover	1	51	Small wheel	1
8	Allen screw M6×30	2	52	Bearing 6000-2RS	1
9	Spring washer 6	3	53	Bearing press plate	1
10	Flat washer 6	3	54	Washer 5	3
11	Upper cover	1	55	Screw M5×12	3
12	Upper flange	1	56	Rotor	1
13	Diamond saw blade	2	57	Bearing 627-2RS	1
14	Positioning plate for adjusting	6	58	Bearing sleeve	1
15	Lower flange	1	59	Ring	1
16	Dust retaining ring	1	60	Carbon brush cover	2
17	Shaft	1	61	Carbon brush holder	2
18	Screw M4×10	5	62	Carbon brush	2
19	Spring washer 4	12	63	Brand label	1
20	Baffle for dust	1	64	Wind fence	1
21	Active guard	1	65	Screw ST4,2×65-FS	2
22	Lower fixed guard	1	66	Stator	1
23	Allen screw M6×25	1	67	Drag spring 13×0.6	2
24	Elastic gasket	1	68	Housing	1
25	Pillar for guide wheel	1	69	Parameter laber	1
26	Flat washer 8	1	70	Screw ST4,2×14-F	11
27	Tube for guide wheel	1	71	Electronic muti-fuction	1
28	Guide wheel	1	72	Screw M5×65	2
29	Screw M8×30	1	73	Spring washer 5	2
30	Dust caser	1	74	Washer 5	2
31	Washer 4	10	75	Right handle	1
32	Sealing washer for dust	1	76	Capacitor	1
33	Dust tube	1	77	Switch	1
34	Dust cover	1	78	Switch button	1
35	Screw M4×16	4	79	Cable jacket	1
36	Front cover	1	80	Cable	1
37	Sealing washer 15×27×4	1	81	Compression spring 5,3× 0.7×16	1
38	Bearing 6201-2RS	1	82	Unlocking button	1
39	Bearing press plate	1	83	Left handle	1
40	Screw M4×12	3	84	Pressing board for cable	1
41	Semi-circular 4×13	1	85	Side handle	1
42	Big gear	1	86	Special wrench	1
43	Shaft washer elastic 12	1	87	chisel	1
44	Bearing HK081410	1	88	Handle sleeve	1

ASSEMBLY DIAGRAM

